

# Connection via 3G and 4G

To connect to the networks of mobile operators, it is possible to use 4G routers with Ethernet interfaces.

---

The server also supports some models of USB modems, for example, Huawei E8372. When connected, the USB modem will be displayed in SafeUTM as a new Ethernet interface.

---

Revision #2

Created 25 August 2022 20:57:32 by Val Redman

Updated 13 October 2022 15:16:20 by Val Redman