


Connecting Keenetic via IPsec

On the SafeUTM side, configure the connection settings in the **Services -> IPSec -> Devices** section.

On the Keenetic device side, use the following encryption protocol settings:







Revision #7
Created 2022-08-27 17:08:56 UTC by Val Redman

Updated 2022-10-13 15:39:38 UTC by Val Redman